



DEPARTURE ROUTE DESCRIPTION

TAKE-OFF RWY 24R: Climb on SSJ VOR/DME R-238. Thence . . .

BRUNO 1A (BRUNO1A): direct to cross TOROS at or above 2000. Direct to IBZ NDB. Direct to BRUNO. Maintain 4000 except as cleared by ATC.

DRAGO 1A (DRAGO1A): direct to cross TOROS at or above 2000. Turn right direct ADX NDB. Direct to DRAGO. Maintain 6000 except as cleared by ATC

ESPOR 1A (ESPOR1A): direct to cross TOROS at or above 2000. Turn right direct ADX NDB. Direct to ESPOR. Maintain 6000 except as cleared by ATC

GALAT 1A (GALAT1A): direct to cross TOROS at or above 2000. Turn right direct ADX NDB. Direct to GALAT. Maintain 6000 except as cleared by ATC.

IBIZA 1A (IBZ 1A): to cross TOROS at or above 2000, direct IBZ NDB. Maintain 4000 except as cleared by ATC

ISTER 1A (ISTER1A): to 4000. Turn left direct PTC NDB. Turn left to follow MHN VOR/DME R-241 direct to MHN VOR/DME. Direct to ISTER. Maintain 4000 except as cleared by ATC.

MAHON 1A (MHN 1A): to 4000. Turn left direct PTC NDB. Turn left to intercept and fly MHN VOR/DME R-241 direct MHN VOR/DME. Maintain 4000 except as cleared by ATC

MEBUT 1A: to 4000. Turn left to intercept and fly SSJ VOR/DME R-208 to MEBUT. Maintain 4000 except as cleared by ATC

MEROS 1A (MEROS1A): to 4000. Turn left direct PTC NDB. Turn left to follow MHN VOR/DME R-241 direct to MHN VOR/DME. Direct to MEROS. Maintain 4000 except as cleared by ATC.

MORSS 1A (MORSS1A): to 4000. Turn left direct PTC NDB. Turn left to follow MHN VOR/DME R-241 direct to MHN VOR/DME. Direct to MORSS. Maintain 4000 except as cleared by ATC.

OSGAL 1A: to 4000. Turn left to intercept and fly ADX NDB track 128° to intercept MJV VOR/DME R-166 direct OSGAL. Maintain 4000 except as cleared by ATC

TURIA 1A (TURIA1A): direct to cross TOROS at or above 2000. Turn right to follow MJV VOR/DME R-272 to GATOS. Direct to TURIA. Maintain 4000 except as cleared by ATC.

TAKE-OFF RWY 24L: Climb runway heading to 600, turn right to integrate on RWY 24R departure procedures.